

**INSTRUCTIONS FOR APPLYING THE HULL NUMBERS (TWO BOW NUMBERS AND ONE TRANSOM NUMBER)**

You have in your packet two bow numbers and one transom number. To apply:

1. The bow numbers shall be placed on either side of the bow so that the top edge of the sticker is no farther than 2" from the lip of the gunnel, and the top forward corner of each sticker is no farther aft than 5" from the bow.
2. The stern number shall be placed on the starboard side of the transom so that the top edge of the sticker is no farther than 2" from the top of the gunnel and the top starboard corner of the sticker is no farther than 2" from the starboard edge of the transom.